

Instructions for AMPS mounting top plate

1. Remove the top plate from your existing mount system and replace with the AMPS plate using the original screws.
2. Attach the GPS or XM radio cradle from the manufacture, using the screws provided with the kit. (Garmin SPIII cradle uses $\frac{3}{4}$ " flat head screws, Garmin 2610/2620 uses 1" flat head screws and XM radio uses $\frac{1}{2}$ " button head screws)
3. Attach your GPS or XM radio unit to the cradle in normal manner. (As you tighten the screws the rubber nuts will expand and grip the plate securely, do not over tighten.)